

## Monster Brass™



- 1. Clean flash and parting lines with a knife, file or sandpaper.
- 2. You can assemble your Monster Metals™ product one of three ways:
  - a. Solder NOTE: Assemble your pieces with a cool iron. This metal has a melting point of 450°. A hot iron could result in melting of the product.
  - **b.** Use a glue-like "super glue" or an epoxy and simply glue the parts together.
  - c. You may use a combination of both A and B.
- 3. Assemble entire casting before you begin your glass work.
- **4.** Paint or apply patina to your casting before you attach the glass. This will make handling easier.
- Thoroughly clean down to the bare metal all areas where glass work will be soldered.
- **6.** After glass has been attached, you may touch up solder joints, seams, and beads with paint or patina.

## ©2016 Monster Metals<sup>TM</sup>

Monster Metals<sup>™</sup> castings and patterns are protected by copyright laws worldwide and may not be reproduced without the explicit written permission of Monster Metals<sup>™</sup>, Inc.